



LAXWORX HARD WALL REBOUNDER ASSEMBLY INSTRUCTIONS



Hardware

Complete list of hardware is on the drawing. Tools included or you can use your own 7/16" and 3/4" wrenches and sockets for easier assembly.



Main Components

Left Leg (1)
Left Leg Extension (1)
Right Leg (1)
Right Leg Extension (1)
Wheel/Axle Assembly (2)
Front X Brace Bar (1)
Rear X Brace Plate (1)
Main Body (1) See Below



STEP 3

Bolt the Left and Right Legs to the Main Body using four 7/8" x 1/2" Hex Bolts and four 1/2" Lock Washers into the threaded holes on the back as shown.



STEP 4

Bolt the Wheel/Axle Assemblies (2) to the Main Legs using the two 1/2" Hex Nuts.



STEP 1

Using the center set of holes, bolt the Left Leg Extension to the Left Main Leg using four 3/4" x 1/4" Hex Bolts and four 1/4" Flange Nuts. Repeat for Right Side Main Leg. A different set of holes can be used to adjust playing angle later if desired.



STEP 5

Bolt the Rear X Brace Plate to the back of the Main Legs using the four 3/4" x 1/4" Hex Bolts and four 1/4" Flange Nuts as shown.




STEP 2

Lay the Main Body face down on a soft surface to avoid scratching the surface. A blanket on the ground or the shipping box will work well for this.



STEP 6

Bolt the Front X Brace Bar to the front of the Main Legs using the two 1-1/2" x 1/4" Hex Bolts and two 1/4" Flange Nuts as shown.



STEP 7

Rotate the Hard Wall Rebounder into the upright position and you are ready to use.